




MBA

Handles - Clean Line - Style 2



Assembly Instructions: Carefully fit the handle onto slightly chamfered shaft end and push as far as possible by hand, then tap the handle with plastic or wooden mallet until firmly in place. This handle in white colour with bright finish has been designed for application on medical and hospital equipment and on food processing machines whose part must be frequently cleaned for hygienic reasons. Its shape is compact thus with no cavities, avoiding any unhealthy residue deposits.

High impact strength special technopolymer, in white similar to RAL 9002 with bright finish.

Resistant to solvents, oils, greases and other chemical agents.

Push fitting on plain shaft made from standard h9 tolerance bright drawn stock bars.

Elastic coupling: the handle is not affected by vibrations and does not tend to loosen.

Handles - Clean Line - Style 2

Part Number	Diameter (D) mm	Hole Size (d)	Hole Depth (h) mm	Base Diameter (d1) mm	Length (L) mm	Material	Colour	Style
	<i>inches</i>		<i>inches</i>	<i>inches</i>	<i>inches</i>			
# 151202	15.00 <i>0.591</i>	6.00	17.00 <i>0.669</i>	12.00 <i>0.472</i>	25.00 <i>0.984</i>	Duroplast	White	Handle
# 151212	20.00 <i>0.787</i>	8.00	21.00 <i>0.827</i>	14.00 <i>0.551</i>	32.00 <i>1.260</i>	Duroplast	White	Handle
# 151222	26.00 <i>1.024</i>	10.00	30.00 <i>1.181</i>	17.00 <i>0.669</i>	42.00 <i>1.654</i>	Duroplast	White	Handle

Indicates item not stocked at time of printing - Please enquire for lead time

E&OE Pricing and all details subject to change without notice - Copyright Miniature Bearings Australia Pty Ltd

MBA Size Listings are a guide to sizes only and must not be solely relied on for critical design information.



DISTRIBUTED BY

Ask us to put your name and address here

<http://www.minibearings.com.au/product>

Ph +61 7 3245 7977

Fax +61 7 3245 1017

Catalogue requests to catalogues@minibearings.com.au

